

SWP-2

Scan Window Protector for Opticon OPN-2001, OPN-2006 and RS-2006

This custom made Scan Window Protector is made from the best grade protection foil available on the market.

Designed to fit on the following Opticon scanner models:



The Scan Window Protector will also fit the discontinued models OPN-2002 and OPN2005 as they have the exact same scan window dimensions.

-  Scratch resistant
-  Crystal clear
-  Repair effect
-  Residue-free removal



SWP-2

APPLICATION INSTRUCTIONS

How to apply the Scan Window Protector (SWP):

Place the OPN, the SWP and a microfibre cloth on a solid surface which is free of dust. Then wash your hands thoroughly. Clean the scan window with the microfibre cloth to remove dust and dirt marks.

On one side you will find a small area which is the starting point to peel (indicated by the grey area in the image). The thinner part is the film that protects the actual SWP.



Peel the film off halfway and begin to apply the SWP aligning it from one side of the scan window.

Caution: Do not touch the adhesive side of the SWP with your fingers!

Slowly peel off the remainder of the film and apply the rest of the SWP to the scan window.

If the SWP is not positioned centrally after having been applied, use some normal sticky tape to remove it from the scan window and start again.

REMOVAL INSTRUCTIONS

Use some normal sticky tape and apply this on top of the SWP. Lift and remove the SWP from the scan window. Clean the window with a microfibre cloth if any dust or dirt marks are visible on the scan window. A new SWP can be applied now.