

Legal Notices

This manual and any examples contained herein are provided "as is" and are subject to change without notice. JNC makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. JNC shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Reproduction, adaptation or translation of this manual is prohibited without prior written permission of JNC Service B.V.

CAUTION: This Quick Reference Guide may be revised or withdrawn at any time without prior notice.

This document provides basic instructions for setting up your DOKKi.eu CMT-1 docking station.

The CMT-1 will fit Opticon scanner models OPN-2001, OPN-2005 (discontinued) and OPN-2006.

As new models are released continuously, make sure to check our website for the list of compatible models first if your models isn't listed here!



CMT-1 compatible models



Other models (for example the OPN-2002, OPN-2003 and OPN-2004) won't fit. Trying to insert unlisted models will result in damage to the CMT-1 and other scanner model!

BOX CONTENTS

The box contains the CMT-1 docking station. Promotional items aren't listed here.

DRIVER INSTALLATION

The DOKKi.eu CMT-1 itself does not need a separate driver. The only driver that needs to be installed on your PC is the appropriate driver for your scanner model that you wish to use on the CMT-1. If not already done so, please follow the instructions for driver installation in the corresponding manual that belongs to your scanner model.

PHYSICAL CONNECTION

Connecting your CMT-1 docking station to your host computer is done with the original USB host cable that was supplied with your OPN scanner.

1. Connect the USB A (male side) of the host cable to a free USB port on your PC;
2. Connect the mini-USB (mini B5 male side) connector on your USB host cable to back of your CMT-1 docking station.

You are now ready to use your CMT-1 docking station!



DOCKING YOUR SCANNER



Hold the scanner between your thumb and index finger on the OPN's body where USB connector is situated in the side (thus, not in the middle but more to the left side). Simply connect your OPN scanner to the docking station by gently placing the OPN over the CMT to align the connectors. When aligned press the scanner down to secure the connection.



Press firmly but never use excessive force when pressing down as this might damage the connectors!
Check for obstructions on both connectors and retry connection.

TROUBLESHOOTING

If you are experiencing any problem with the CMT-1 the first thing to check is if the OPN functions correctly when connected directly to the USB cable. Do so by unplugging the USB cable from the back of the CMT-1 docking station and plug it directly into your OPN. If it does function properly continue at the checklist below, otherwise the problem is with your OPN itself, the USB cable or the PC (USB port and/or driver(s)).

Checklist

| | |
|------------------|---|
| No power | <ul style="list-style-type: none">- Is the OPN scanner firmly pressed into the docking station?- Are the cables properly connected?- Is the PC switched on? |
| No communication | <ul style="list-style-type: none">- Is the OPN fully charged?- Are the OPN drivers properly installed?- Are there no other programs polling on the same COM-port? |

If you have any questions regarding the use of your docking station please contact your dealer.

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND
BY THE LIABILITY AND WARRANTY CONDITIONS.

Limited Warranty, Liability and Disclaimers

This Limited Warranty and Disclaimer extends only to products purchased directly from DOKKi.eu or a DOKKi.eu Authorized Dealer as stated on our website (<https://www.dokki.eu/dealers>).

Under no circumstance JNC will be liable for any direct, indirect, incidental, special, consequential, punitive, or exemplary damages, including but not limited to, damages for loss of profits, revenue, income, goodwill, use, data, or other intangible losses that arise from use or inability to use the docking station, even if JNC has been informed about the possibility of such damages.

This DOKKi.eu docking station is warranted for a period of one year after purchase, covering defects in material and workmanship. JNC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. The warranty does not apply to defects resulting from (a) improper or inadequate maintenance measures taken; (b) interfacing parts or supplies not supplied or authorised by JNC; (c) unauthorized modification or misuse; (d) operation outside the applicable environmental parameter limits specified for the product; or (e) improper site preparation or maintenance for installation.

Always return the product through the dealer where initially bought. Follow the instructions provided by your dealer.